



Finger


Assembly of coupling against pontoon





Necessary equipment:






Prestressing factor:
M12 = 87 Nm
M20 = 412 Nm




Spanner for M12 (M16)

NB!


- Do not tighten until defomation of any steel or plastic parts.
- Do not put the steel construction directly at the ground to prevent damage at the surface.



2 Installed at C-Profile



3 Installed at standard steel pontoon.



4 Installed at pontoon with wood fender.

