Ørsta Road railing

One-sided

Tube formed guardrail

Installation manual





Installer:

Vik:

6893 Vik i Sogn

Ørsta:Skorgeura
6150 Ørsta

Tlf: +47 57 69 86 50 Faks: +47 57 69 86 60

Tlf: +47 70 04 70 00 Faks: +47 70 04 70 04 firmapost@vikorsta.no

firmapost@vikorsta.no

L

Installation manual Ørsta Road Railing One-Sided

Index

1.	Important	3
2.	Important Description	3
3.	Level of performance	3
4.	Installing	3
	4.1 Soil and placement	3
	4.2 Installing the posts	
	4.3 Installing the front tube	3
	4.4 After installation	4
5.	Maintenance	4
	5.1 Cleaning	4
6.	List of components	4
7.	Marking	4
8.	Marking Drawings	5

Copyright[®] , Vik Ørsta A/S

All right reserved. No part of this book may be reproduced or transmitted in any form or by any means, digital or permission in writing by Vik Ørsta A/S.

All statements and technical information are based on results obtained under typical conditions. It is the responsibility of the recipient to clarify with us that the information is appropriate for the specific use intended by the recipient. Please check with our Customer Service for further information.

www.vikorsta.no Foretaksregisteret: NO 985 001 952 Bankkonto: 7262.05.16369

Installation manual Ørsta Road Railing One-Sided

1. Important

Proper installation and repair is essential to ensure the systems maximum performance.

2. Description

Ørsta Road Railing is a steel road restraint system that is designed to enhance safety on the roads.

The system has successfully been tested according to class N2 described in EN 1317-2.

The system is based on steel posts with post distance of 3 meters and longitudinal steel tubes.

In a collision the system is designed to lead the vehicle back on the road.

The bolts are an important part of the systems function and this manual should be read carefully before installation is started.

3. Level of performance

According to EN-1317

Post distance	Containment level	Working width	Impact severity level
3,0 m	N2	1,25 m/W4	Α

4. Installing

4.1 Soil and placement

The soil where the barrier is placed should be of sufficient quality to ensure the guardrails function.

The posts should bend and not break up true the soil or be pulled up when the barrier is hit.

4.2 Installing the posts

The posts should be installed with a distance of 3 meters.

The holes for the posts should normally be pre-drilled or pre-rammed before installing the post. They should be drilled to the correct level or deeper, to ensure that there is no need to ram the posts after they are placed.

After alignment and height adjustment, parts of the hole around the post should be filled with gravel to lock the post in the correct position.

4.3 Installing the front tube

The longitudinal tubes have rectangular holes placed with different distance from the ends. They must be installed with the shortest distance after the post. For details regarding connection between post to tube and tube to tube, see chapter 8. Drawings.

www.vikorsta.no

N-6893 Vik i Sogn

Installation manual Ørsta Road Railing One-Sided

4.4 After installation

When the guardrail is installed and adjusted, the holes around the post should be fully refilled.

5. Maintenance

There are no general inspections intervals for this guardrail itself. Inspections intervals have to be determent based on local factors such as volume of traffic, risk of damage, climate etc.

The guard rail should be inspected regularly and if displaced or damage, it should be adjusted and repaired.

All damage profiles should be replaced with new when repaired.

5.1 Cleaning

Cleaning can be done with water and any type of Ph neutral detergent.

6. List of components


Art.no	Pos.	Description	Detail
	no.		drw.
5111500	1	C- POST 100x50	T-0135
5132200	2	FRONT TUBE, TUBE Ø89 L= 6 M.	T-0173
5111520	3	CONNECTION TUBE Ø80, FRONT TUBE	T-0126
4116104	4	FLATHEAD BOLT M16X104 INCL. NUT AND WASHER	T-0419
9266	5	PLASTIC BRACKETT FOR T-BOLT, FRONT TUBE	T-0166
4110034	6	T-BOLT M10X35 4.6VZN	T-0112
4110035	7	FLANGE NUT M10	T-0189

<u>Note:</u> Please check that all bolts/fasteners are placed correct and all bolts-washer-nuts-connections are normally/proper fastened/tighten.

7. Marking

If everything is done and installed according to this installation manual, the guardrail can be marked with the CE-mark. This mark shall be placed at the end (the starting end) of the installed guardrail.

Installation manual Ørsta Road Railing One-Sided



Vik Ørsta AS

firmapost@vikorsta.no
Tel: +47 57 69 86 50
Fax: +47 57 69 86 60

www.vikorsta.no Foretaksregisteret: NO 985 001 952 Bankkonto: 7262.05.16369

N-6893 Vik i Sogn